



## Communicate Ear dB Blocker®

*The Communicate Ear dB Blocker® allows in-ear radio reception as well as exceptional hearing protection.*

**T**he Communicate Ear dB Blocker® allows in-ear radio reception as well as exceptional hearing protection. It is custom fit to the individual wearer for maximum comfort using Skinsoft™ medical silicone. It is suited to anywhere two-way radio communication is used.



### RECOMMENDED USES

- Any Industrial Application where radio communication is required
- Police/Fire/Security
- Sporting Venues
- Motorcycle Riding (Radio)
- Warehouses

The use of this hearing protector is not limited to the above applications. Where communications privacy is a concern use the Communicate Ear dB Blocker®.

### FEATURES

- Achieves an NRR of 23 (Closed with radio button in)
- NRR 22 (Open with radio button out)
- Volume limiting vent filter between radio button and ear
- Custom molded to each employee
- Custom molded to each individual employee
- Cast retained for 5 years
- Coloured exterior



BENEFITS

- A High degree of noise protection while permitting radio communication
- Lose only one dB of protection when button not attached
- Hearing loss from radio transmission eliminated due to custom filtering placed after receiver button which eliminates damage from feedback and high volume transmissions
- A hearing protector that is comfortable to wear will enhance compliance with the hearing protection program
- Hearing protectors that are custom fitted to each worker, give each worker the same amount of hearing protection
- Less noise induced stress leading to less accidents and absenteeism
- Dual venting allows the ear to equalize pressure and allow outside communication to be heard
- Communicate Ear dB Blocker® can double as a Vented dB Blocker® when receiver button is removed
- Lost or different models can be reordered over the phone
- Colour option makes them easier to find if dropped and allows managers to see if employees are wearing them at glance around plant floor



SPECIFICATIONS

- Made of Skinsoft™ medical grade silicone
- Hypoallergenic
- Non-porous
- Antibacterial Soap and Water for Maintenance
- Durometer of 30 (800 PSI tear strength)
- 25 lbs tear strength on metal anchor
- Product inert to 500 F
- NRR 23 with Receiver Button attached
- NRR 22 without Receiver Button
- Cord can be attached when Receiver Button is removed to join with other HPD
- Colours Available - Blue, Green, Orange, Red, Black, Purple, and Clear



CARE AND MAINTENANCE

- Lubrication with Petroleum Jelly essential for first 2 weeks
- Wash regularly with soap and water
- Re-lubricate as needed after washing

